



**Installation and Operation Manual  
for Perenio® PECLS01  
Leak Sensor**



## Introduction

The Leak Sensor is a device that provides for timely detection of leakage of water and other liquids in the area of installation. It can be used as a part of the **Perenio Smart Building Management System** after being connected via the Control Gateway/IoT Router, or as a standalone leakage alarm device.

The present Manual contains a detailed description of the Leak Sensor, as well as instructions for its installation and operation.

## Copyrights

Copyright of ©Perenio IoT spol s r.o. All rights reserved.

The **Perenio**<sup>®</sup> trademark is owned by *Perenio IoT spol s r.o.* (hereinafter referred to as the *Perenio IoT*). All other similar trademarks and names, as well as logos and other symbols are the property of their respective owners\*.

All materials under **Perenio**<sup>®</sup> tradename contained therein are protected in accordance with international and local laws including Acts on copyrights and related rights.

Any reproduction, copying, publication, as well as further distribution or public display of materials contained in the present document (whether in full or in part) shall not be allowed until an appropriate permission of the copyright owner is obtained. Any unauthorized usage of materials contained herein may lead to civil liability and criminal prosecution in accordance with applicable laws.

Any eventual mentioning of other company names and equipment in the present document is made solely for the purpose of clarifying and describing the device operation and shall not infringe on the third party's intellectual property rights.

\***ZIGBEE** is the registered trademark of *ZigBee Alliance*; **iOS** is the registered trademark of *CISCO TECHNOLOGY, INC.*; **Android** is the registered trademark of *Google Inc.*; **Google Play** is the trademark of *Google Inc.*; **App Store** is the registered trademark of *Apple Inc.*; **Linux** is the registered trademark of *Linus Torvalds*.

## Responsibility and Technical Support

The present document is prepared in accordance with all necessary requirements and contains detailed information on the device installation, configuration and control valid as of the date of its issue.

*Perenio IoT* reserves the right to modify the device and make corrections or changes to this document without prior notice of the User, and shall not be responsible for any potential negative consequences which may arise from the use of an outdated version of the document, as well as for any possible technical and/or typographical errors, either omitted or accidental, or any related damage that may result from the document transfer or the use of devices.

*Perenio IoT* shall make no guarantee with respect to any data contained herein including but not limited to the device merchantability and fitness for a particular purpose.

In case of any discrepancies between language versions of this document, the Russian version of this User Manual shall prevail.

For any technical issues, please contact your local *Perenio IoT* representative or the Tech Support Department at **perenio.com**.

The most common problems may be found in Section 7 of the present document and at **perenio.com** where you can also download the latest version of this Installation and Operation Manual.

Manufacturer:

*Perenio IoT spol s r.o.*

Na Dlouhem 79, Ricany – Jazlovice 251 01, Czech Republic

**perenio.com**

## Conformance to Standards



The device is CE certified and complies with requirements of the following Directives of the European Union:

- 2014/53/EU Radio Equipment Directive (RED);
- 2004/30/EU Electromagnetic Compatibility Directive.



The device complies with the UKCA marking requirements for selling the device in the UK



The device has passed all procedures of assessments established in Technical Regulations of the Customs Union and conforms with standards of the Customs Union



The device complies with the requirements of Restriction of the Use of Certain Hazardous Substances in Electronic and Electrical Equipment (2011/65/EU Directive)



The device complies with requirements of the Technical Regulations of the Republic of Belarus TR 2018/024/BY (Telecommunications. Security)



The national conformity mark of the Ukraine indicating that the device meets requirements of all applicable technical regulations



The crossed-out trash can symbol is used to label electrical and electronic equipment, and indicates its separate collection.

The symbol is given in accordance with the Directive 2012/19/EU on Waste Electrical and Electronic Equipment (WEEE)\* and indicates that this equipment requires separate collection at the end of its life and must be disposed of separately from unsorted household waste.

To protect the environment and human health, please dispose of used electrical and electronic equipment according to approved safe disposal guidelines



Details on available Certificates are specified in Section 6 of the present document. For copies of Certificates and Reports, please visit a corresponding Section at **perenio.com**.

BG	CZ	DE	ES	FR
GR	IT	KZ	LT	LV
NL	NO	PL	RO	RU
SE	SK	TR	UA	UK

## Table of Contents

Introduction .....	3
Copyrights .....	3
Responsibility and Technical Support.....	4
Conformance to Standards.....	5
Table of Contents.....	7
1 General Description and Specifications .....	9
1.1 General Purpose .....	9
1.2 Technical Specification .....	11
1.3 Scope of Delivery.....	12
1.4 Packaging and Labelling .....	13
1.5 Safe Operation Rules .....	13
1.6 Standalone Operation of Perenio <sup>®</sup> Sensors .....	14
2 Installation and Setup.....	15
2.1 First Installation and Configuration .....	15
2.2 Sensor Control Panel.....	19
2.2.1 Battery Level .....	19
2.2.2 Event History .....	19
2.2.3 Additional Settings .....	20
2.3 Leak Sensor Tightness .....	21
2.4 Changing the Room or Location for the Sensor .....	22
2.5 History and Push-Notifications.....	23
2.6 Battery Replacement.....	24
3 Maintenance and Repair.....	25
4 Warranty Obligations .....	26
5 Storage, Transportation and Disposal of Devices .....	29
6 Other Information .....	30
7 Troubleshooting .....	31
8 Glossary.....	32

## Figures and Tables

Figure 1 – Leak Sensor Exterior .....	9
Figure 2 – Buttons and Indicators .....	10
Figure 3 – Scope of Supply .....	13
Figure 4 – Examples of Installation.....	15
Figure 5 – Add new device (Sensor) procedure .....	18
Figure 6 – Ensuring tightness of the Leak Sensor casing .....	22
Figure 7 – Positioning of the battery in the Leak Sensor .....	24
Table 1 – Light indicator states .....	10
Table 2 – Basic Technical Specifications of the Leak Sensor .....	11
Table 3 – Typical Errors and Troubleshooting Methods.....	31

## Connection to the Perenio Smart Mobile App

A. SWITCHING ON AND INSTALLATION OF THE LEAK SENSOR.....	16
B. LOGIN TO THE EXISTING USER ACCOUNT.....	16
C. CONNECTION TO THE CONTROL GATEWAY/IOT ROUTER .....	17



## 1 General Description and Specifications

### 1.1 General Purpose


The **Perenio<sup>®</sup> PECLS01** Leak Sensor is a device intended to alert users in the case of flood in the room. This device is used as part of the **Perenio Smart Building Management System** and is suitable for detection of leakage of water and some other liquids in the place of its installation.

The **PECLS01** Leak Sensor has a number of distinctive features, namely:

- Easy to install and control;
- iOS and Android smartphone compatibility;
- Support of Zigbee Protocol;
- Triggering accuracy (in the case of floods);
- Impact- and heat-resistant casing material with IP67 Protection Class;
- Alarm level – 65dB;
- Floating function;
- Operation with one battery for up to 16 months;
- Standalone operation;
- Small size and stylish design.



**Figure 1** – Leak Sensor Exterior



**Figure 2 – Buttons and Indicators**

### Buttons, Ports and Indicators

- LED** It shows the device status
- Speaker** It gives an alarm in the case of flooding the room
- Reset Button** It is used to reset Leak Sensor settings, as well as for the Leak Sensor to be detected by the Control Gateway/IoT Router
- Leak Detectors** The Sensor will be actuated in the case when both detectors will be covered with water or other liquids

Table 1 – Light indicator states

Indicator	Status	Description
Red	Blinking slowly	Sensor is on, and the process of connecting to the IoT Router/Control Gateway and activation in the mobile app is started
	Blinking fast	Reset was successful, the sensor was deleted from the mobile app
	Off	The sensor is on, activated in the mobile app, and is in the working order
		Sensor is off

**ATTENTION!** All Products and the Mobile Application of the Company (including any future software and hardware whether in-house or third-party developed) are not intended for emergency responses and cannot be used as fire-extinguishing equipment and/or for emergency intervention, including but not limited to fires, flooding, gas leaks or explosions, burglary and theft, as well as natural disasters and other force majeure circumstances leading to damage and/or losses incurred by the Client or caused to their estates, personal property and/or other products, devices, personal data and privacy.

## 1.2 Technical Specification

Table 2 – Basic Technical Specifications of the Leak Sensor

Parameter	Value
Article	PECLS01
Microprocessor	DSP (JN5169)
Communication Technology	Zigbee HA 1.2 (IEEE 802.15.4)
Operating Frequency	2.3GHz to 2.5GHz
Connection Radius	up to 40 meters (open area)
Zigbee Antenna	Type: Built-in Transmitting Power: 10dBm Receiver Sensitivity: -90dBm Antenna Gain: 1dBi Repeater: N/A
Number of Detectors	Two
Liquid Level	Triggering level: 1.5mm (height)
Alarm Type	Siren
Alarm Level	up to 65dB
Standalone Operation	Available
Power Type	CR123A Battery (1300mAh, 3V), 1 pc.
Power Consumption	Standby Mode: not more than 0.2mA Alarm Mode: not more than 40mA

Parameter	Value
Battery Level	Yes (Available in the Mobile App)
Operating Temperature	0°C to +50°C
Operating Humidity	20°C to +90°C RH
Storage Temperature	-20°C to +65°C
Storage Humidity	20°C to +93°C RH
Installation	On a horizontal surface (for indoor installation). The outdoor installation is possible in the case requirements to the operating temperature and humidity are respected.
Casing Material	ABS/PC
IP Protection Class	IP67
Color	White
Dimensions (L x W x H)	60mm x 60mm x 21mm
Weight	32g (48.8g with accessories)
Warranty Period	24 months
Service Life	24 months
Certification	CE, EAC, RoHS, UA.TR

### 1.3 Scope of Delivery

The following items and accessories are supplied within the **Perenio® PECLS01** Leak Sensor package:

1. PECLS01 Leak Sensor (1 pc.)
2. Battery (CR123A) (1 pc.)
3. Quick Start Guide (1 pc.)
4. Warranty Card (1 pc.)
5. Sticker (1 pc.)



**Figure 3 – Scope of Supply\***

\* Images of accessories are provided for informational purposes only

## 1.4 Packaging and Labelling

The **Perenio<sup>®</sup> PECLS01** Leak Sensor is supplied in an individual blister package of 171mm x 126mm x 27mm (L x W x H) containing the full name and marking of the device, the list of accessories provided and basic technical specifications thereof, as well as the date of manufacture and information about the Manufacturer of devices.

Weights of the blister package are as follows:

- Net weight: 49g;
- Gross weight: 80g.

## 1.5 Safe Operation Rules

For the proper and safe operation of **Perenio<sup>®</sup>** Sensors, follow the instructions and safety procedures described in the present Manual. The Manufacturer shall not be liable for any damage caused as a result of improper operation of devices.

### Safe Operation Conditions

1. The Users shall observe storage/transportation conditions, as well as the operating temperature mode of the device as declared by the Manufacturer.
2. The Users shall observe recommendations on sealing as specified in par. 2.2 of the present document.

3. Do not use the device to detect aggressive liquids such as acids, chemicals, gasoline, etc. and non-conductive liquids such as distilled water.
4. The User must not disassemble or attempt to repair the device on their own.
5. The User must not drop, throw or bend the device.
6. In order to avoid personal injury, it shall not be allowed to use the cracked or in any other way damaged device.
7. Use dry cloth or cloth soaked in a small amount of water for cleaning (don't use harsh chemicals/cleaning agents). The device must be powered off before cleaning.
8. Children shall not be allowed to use the device unsupervised and/or play with it.

## **1.6 Standalone Operation of Perenio® Sensors**

The Control Gateway/IoT Router is not necessarily required for all **Perenio®** Sensors in order to alert Users on potentially dangerous situations.

So, the Leak Sensor can operate as a standalone device, i.e. when it detects leakage in a room, it starts beeping. However, to receive notifications on a smartphone and run active scenarios, the User must have an installed mobile app and an activated Control Gateway/IoT Router, as well as unite the above devices in a system.

## 2 Installation and Setup

Before installation, the User shall select a flat horizontal installation area for the device.

**NOTE.** It is not recommended to install the device in areas with a high level of noise and a high-frequency interference. Reinforced concrete floors may reduce the distance of wireless signal transmission.

It is recommended to install the Leak Sensor at a minimum distance from the Control Gateway/IoT Router.

Figures below show possible installation locations for the Sensor.



**Figure 4 – Examples of Installation\***

\* Images are provided for informational purposes only

The entire process of setting-up the Sensor can be divided into several key stages:

- Logging in to the User Account of the **Perenio Smart** Mobile App;
- Checking for the availability of the CG /IoT Router connected to the mains and the Internet;
- Connection of the Sensor to the Control Gateway/IoT Router.

### 2.1 First Installation and Configuration

In order to connect the Leak Sensor to the Control Gateway/IoT Router through the **Perenio Smart** Mobile App, it is necessary to perform the following steps:

1. Unpack the Sensor and switch it on (See par. **A** below).
2. Login in to the **Perenio Smart Building Management System** User Account (See par. **B** below).

3. Connect the Leak Sensor to the Control Gateway/IoT Router (See par. **C** below).
4. Enter the desired Sensor name and select the Room of installation.
5. Install the Sensor in the selected room.

## A. SWITCHING ON AND INSTALLATION OF THE LEAK SENSOR

To install the **Perenio® PECLS01** Leak Sensor, follow steps below:

1. Unpack the device.
2. Select suitable installation area near a potential source of flood (water valve, washing machine, radiators, etc.).
3. Unscrew the Sensor casing and switch on the device by removing the battery isolation film.
4. Reassemble the Sensor casing (See par.2.2 below) and install it in the desired area.

After the above Steps 1-4 are successfully completed, the Leak Sensor is considered to be installed and ready for operation.

**NOTE.** If the LED starts flashing slowly after removal of the battery isolation film, you can immediately begin connecting it to the Control Gateway/IoT Router and skip **Step d** of par. C. "CONNECTION TO THE CONTROL GATEWAY/IOT ROUTER".


## B. LOGIN TO THE EXISTING USER ACCOUNT

**a.** Enter your e-mail address and password in the login screen.

**b.** Click on the **LOG IN** button.


**NOTE.** If the password was lost, the User can restore it by clicking on a corresponding link on the screen.

To restore a forgotten password, use the e-mail address linked to your User Account, to which instructions on changing the password will be sent.





## C. CONNECTION TO THE CONTROL GATEWAY/IOT ROUTER



- a. Click on the "+" icon in the upper right corner of the Devices tab and select the Leak Sensor in the list;
- b. Select the Control Gateway/IoT Router to which the Sensor shall be connected (This screen will be displayed, only if there are several Control Gateways/IoT Routers activated in the User Account).

**NOTE.** The Control Gateway/IoT Router must be connected to the mains and the Internet, as well as activated in the Perenio Smart App.

- c. Start searching for Sensors;
- d. If the LED flashes slowly after the first power on of the device, proceed to the **Step e**, otherwise press and hold the reset button until the LED Indicator starts blinking rapidly. If the LED goes out after the reset button is released, press it again, otherwise wait for the sensor to complete connection.

**NOTE.** Several sensors may be connected to the Control Gateway/IoT Router at once.


- e. After successful connection, enter the Sensor's name and select the Room.

### C.1. CONNECTION ERRORS


The connection failure of the device may occur due to one of the following reasons:

- a. The device is switched off or at a too long distance from the Control Gateway/IoT Router (4.5 meters);
- b. The Control Gateway/IoT Router is offline;
- c. The LED Indicator was blinking fast before start of the sensor connection (You should remove the sensor battery and insert it back into the casing).

**NOTE.** To eliminate connection failures, follow instructions specified on corresponding screens of the smartphone.




The entire process of the Sensor connection in the Mobile App is shown below.



**Figure 5 – Add new device (Sensor) procedure**

## 2.2 Sensor Control Panel



The Leak Sensor control panel is displayed, when you click on its image in the list of connected devices in the "Devices" tab.

The user can perform the following actions in this control panel:

- View the current state of the device;
- View the battery level;
- View the history of events;
- Make additional setting of the sensor.

**NOTE** that it is not possible to turn off the Armed Mode for the Leak Sensor.

### 2.2.1 Battery Level

The battery level is displayed in the following four (4) levels:

- Fully charged (100% to 95%);
- High level of charge (94% to 75%);
- Average level of charge (74% to 31%);
- Low level of charge (30% to 11%);
- Discharged (10% to 0%).

**NOTE** that it is recommended to purchase additional batteries in advance to ensure stable operation of the sensors.


### 2.2.2 Event History

In this tab, the user can view the status of the sensor, as well as the time when the event occurred.


Functions are as follows:

- “ENTIRE HISTORY” filter, which allows viewing the following events:
  - Changes in the security modes (“Armed”, “Disarmed”);
  - Device actuation events (“Safe”, “Danger”);
  - Notifications about low battery level;
  - Start and completion of the firmware update.
- “ALARMS ONLY” filter, which displays device actuation events for the Armed Mode only;
- Filter by date.

**NOTE** that the number of days available for viewing depends on the Subscription Plan (It is 7 days for free Subscription).



### 2.2.3 Additional Settings




After the Sensor is activated in the Perenio Smart app, the user can make the following settings remotely:

- Change or upload the device image for easier identification of the sensor in the list of connected devices;
- Change the name of the device;
- Add a device to the Room or change the Room of installation;
- Turn on the sound of push notifications;
- Remove the device from the mobile application.

There are two ways to switch to the settings screen, namely:

1. Click on the icon with three dots in the right upper corner of the sensor image in the mobile application and select "Settings".



2. In the control panel, click on the settings icon.



## 2.3 Leak Sensor Tightness


The IP67 Protection Class of the Leak Sensor casing completely prevents the ingress of dust into the device.

It also withstands short-term immersion in water (up to 30 minutes to a depth of no more than 1 meter) provided that the Sensor casing is properly closed and the rubber seal is not damaged.


At the same time, the Sensor is not intended for continuous operation in water.

Although the Leak Sensor will float on the water surface in case of flood, it is necessary to follow rules below to prevent premature failure of the device:

- Do not allow children playing with the Sensor and immerse it in water;
- Keep the Sensor casing closed, since frequent opening-closing of the device may cause damage to the rubber sealing ring which is subject to natural wear;
- Close the Sensor casing according to special marks until a click appears (See Figure below).



6-a – Initial position of the upper and lower parts of the Sensor body relative to each other (The Sensor is NOT CLOSED)




6-b – Final position of the upper and lower parts of the Sensor body relative to each other (The Sensor is CLOSED)

**Figure 6** – Ensuring tightness of the Leak Sensor casing

## 2.4 Changing the Room or Location for the Sensor

When using the Sensor, it may be necessary to change its installation area. The following options are possible:

- 1. Change the room/location** (The CG/IoT Router remains the same) as follows:
  - a. Move the Sensor to another room;
  - b. Make sure that the Sensor is at an allowable distance from the CG/IoT Router;
  - c. Install the Sensor in a new room;
  - d. Change the Room in Sensor settings in the User Account.
  
- 2. Change the room/location** (Connection to another CG/IoT Router is required) as follows:
  - a. Sign in to the Perenio Smart app and select the Location where the Sensor is activated;
  - b. In the Devices tab, select the required Sensor from the list and click on the  icon (Settings);
  - c. In the pop-up window, choose "Disconnect device";
  - d. Move the Sensor to another room/building;
  - e. Make sure that the Sensor is at an allowable distance from the CG/IoT Router;
  - f. Install the Sensor in a new room;
  - g. In the User Account, select the Location where you want to move the Sensor;
  - h. Initiate the Sensor search by the Control Gateway/IoT Router through the Perenio Smart application according to par. **C. "CONNECTION TO THE CONTROL GATEWAY/IOT ROUTER"**.

**NOTE.** The User can manually disconnect the Sensor from the Control Gateway/IoT Router. To do this, press and hold the Reset button on the Sensor until the LED flashes (It usually takes no more than 5 seconds).

To check that the Sensor was successfully disconnected, you should update the list in the Devices tab (Pull the screen down until the progress icon appears and the data is updated). If the sensor is disconnected, it will disappear from the list of connected devices.

## 2.5 History and Push-Notifications

All notifications and other messages including changes in the status of **Perenio<sup>®</sup>** devices are displayed in the "History" tab. The most important messages can be viewed online in the "🔔" notification window in your account.

The following types of notifications are available:

- (Critical) alarms (They always come as push notifications to your smartphone, and are also displayed in the notification window, as well as in the "History" tab of the mobile app; The indication color is red);
- Important messages (They are always displayed in the notification window and the "History" tab; The indication color is yellow);
- Typical events (They are displayed in the "History" tab only; The indication color is not available).

**Alarms.** These are the most important messages, which include notifications about the following events:

- IoT Router battery charging is low;
- The IoT Router runs on battery;
- Motion detection by the camera;
- There is not enough space on the SD card to continue recording video;
- Change of the camera status to "Offline";
- Sensor triggering in the armed mode, including all alarms from smoke and leak sensors (even when the Location is in the disarmed mode);
- Disabling the sensor armed mode;
- Failure to perform the scenario;
- Connection of a dangerous device, and overloading the network (for the Power Link Wi-Fi Smart plug);
- Sudden changes or insufficient voltage, excessive power, temperature and/or consumption (for Power Link (ZigBee) Smart plug);

- Falls and/or overheats of the Eco Smart Heater, or sudden changes in voltage;
- Important updates.

**Important messages.** These are notifications on launches and completion of the camera and the Control Gateway firmware update, as well as notifications about low battery level of the sensor and changing the armed mode for the Location.


**Typical Events.** Various Perenio IoT newsletters, as well as messages about triggering Door & Window/Motion sensor in the disarmed mode.

## 2.6 Battery Replacement

The Leak Sensor can operate with one battery for a period of up to sixteen (16) months. The battery level can be controlled via the Mobile App (Leak Sensor panel). Also, the Sensor will send light and sound signals, if the battery level becomes too low.

In order to properly replace a discharged battery, the User shall observe the following rules:

- Make sure that the new battery is the same as the original (supplied with the Sensor);
- When replacing the battery, the User shall observe the polarity (See below).



**Figure 7** – Positioning of the battery in the Leak Sensor

After battery replacement, the LED of the Sensor will blink.



### 3 Maintenance and Repair

The **Perenio<sup>®</sup> PECLS01** Leak Sensor does not require special maintenance in the normal course of operation. However, in order to maintain the proper state and stable operation of the device it is recommended to perform the following actions from time to time:

- Clean the device casing from dirt and dust at least once every six months;
- Check the rubber seal for signs of normal wear periodically and replace it in a timely manner;
- Test the alarm signal of the Sensor periodically;
- Check for updates of the Perenio Smart app;
- Check for battery condition and replace it in a timely manner;
- Repair mechanical damages to devices (in Service Centers).

The **Perenio<sup>®</sup> PECLS01** Leak Sensor repairs shall be carried out in Service Centers, because casings will have to be opened in the case of any element failure.

In the case of warranty repairs or replacement, the User shall provide the Seller with the sales receipt and the purchased device.

For details on the replacement and repairs of the **PECLS01** Leak Sensor, please contact your local Company representative or the Tech Support Department at **perenio.com**.

---

## 4 Warranty Obligations

The warranty period for the Leak Sensor shall be **Twenty-Four (24) months** from the date of sale to the End User. General-purpose batteries (such as AAA, CR123A, CR2450, etc.) shall not be covered by the warranty of the Manufacturer of IP Cameras, smart hubs and sensors.

The Warranty Card shall be deemed valid provided that it is correctly and completely filled in by the Seller. Upon the purchase, the Customer shall check that both the Serial Number and the Model name of the device correspond to those indicated in the Warranty Card.

Incomplete or illegible Warranty Card shall be deemed not valid. In this case, it is recommended to contact the Seller and ask for a duly filled in Warranty Card. It shall be also allowed to provide the original of the sales/cashier's receipt or such other documentary evidence of the fact and the date of sale of the device. The date of sale shall be the date indicated on the sales/cashier's receipt or other relevant document. If the date of sale is not possible to be determined, the start of the warranty period shall be the date of manufacture of the device.

The Manufacturer shall guarantee that all materials, components and assemblies of **Perenio®** devices are free from defects under normal operation within the warranty period. The limited warranty shall be applied to the first End Customer of **Perenio®** devices only and cannot be transferred to a subsequent customer.

For warranty replacement, the device must be returned to the Seller along with its receipt. Warranty obligations for **Perenio®** devices shall be provided in the country of their purchase only.

### WARRANTY SERVICE PROCEDURE

In the case of any alleged defect or deficiency of the device detected, the Customer shall contact the Authorized Service Center before the warranty period expiration and provide the following:

1. The device with an alleged defect or deficiency.
2. The Warranty Card filled out in accordance with the applicable legal requirements, or the original of the document confirming the purchase of the device, including clear indication of the name and the address of the Seller, as well as the date when this device was sold.

## **LIMITATION OF LIABILITY**

**Perenio<sup>®</sup>** devices SHALL NOT BE SUBJECT TO a free warranty service in the case of identification of at least one of the following damages or defects:

- Any damage caused by force majeure, accidents, and willful or careless acts (omissions) of the Customer or third parties;
- Any damage caused by the impact of other objects including but not limited to exposure to moisture, dampness, extreme temperatures or environmental conditions (or jumps in such conditions), corrosion and oxidation, as well as penetration of food or liquid, and the effects of chemicals, animals, insects and byproducts thereof;
- In the event when the device (accessories and/or components) was unsealed (the seal integrity was violated), modified or repaired by any party other than the Authorized Service Center, including repair works using unauthorized spare parts;
- Any defects or damage caused by improper or unintended use of the device, including operation contrary to available manuals;
- Any defects caused by attempts to connect to incompatible software;
- Any defects caused by natural wear and tear of Products, including bags, casings, batteries or Installation and Operation Manuals;
- In the event when the Serial Number (Name Plates), the date of manufacture or the Model name on the device casing was in any way removed, erased, affected, altered or made illegible;
- In the case of violation of operating procedures and conditions, as well as the device installation instructions described in relevant Manuals;
- Cracks, scratches and other defects caused as a result of transportation and/or operation of the device by the Customer or acts of negligence on their part;
- Mechanical damages that occurred after transferal of the device to the Customer including damage caused by sharp objects, bending, squeezing, falling, etc.;
- Any damage caused by non-conformity with the standards of power supply, telecommunication and cable networks or similar external factors.

THE PRESENT LIMITED WARRANTY IS AN EXCLUSIVE AND THE ONLY PROVIDED GUARANTEE THAT SHALL REPLACE ANY OTHER EXPRESS AND IMPLIED GUARANTEES. THE MANUFACTURER SHALL PROVIDE NO GUARANTEES, WHETHER EXPRESS OR IMPLIED, BEYOND THE DESCRIPTION CONTAINED IN THE PRESENT DOCUMENT, INCLUDING THE IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE CUSTOMER MAY USE DEFECTIVE OR INAPPLICABLE DEVICE AT HIS/HER OWN DISCRETION. THE MANUFACTURER SHALL NOT BE RESPONSIBLE FOR DAMAGE TO OTHER PROPERTY CAUSED BY DEVICE DEFECTS, THE LOSS OF USABILITY OR TIME OR FOR ANY SPECIAL, INCIDENTAL, INDIRECT OR CONSEQUENTIAL DAMAGE OR LOSS INCLUDING BUT NOT LIMITED TO COMMERCIAL

LOSS, LOSS OF PROFITS, LOSS OF CONFIDENTIAL OR OTHER INFORMATION, AS WELL AS DAMAGES CAUSED BY BREAKS IN COMMERCIAL OR PRODUCTION ACTIVITIES DUE TO THE FACT THAT THE DEVICE WAS RECOGNIZED AS FAULTY, DEFECTIVE OR NOT ALLOWED FOR USAGE.

The present limited warranty shall provide the Customer with certain legal rights. The Customer may also have other rights in accordance with the local consumer protection laws that vary from country to country and may not coincide with this limited warranty. For full understanding of the Customer's rights, you shall read local acts.

**NOTE.** The Manufacturer does not produce equipment for *Vital Tasks*. Vital Task Products shall include life support systems, medical equipment, implantation-related medical devices, commercial transportation, nuclear equipment or systems, and any other fields of application where equipment failures may do harm to a humans' health or cause their deaths, as well as result in a property damage.

## 5 Storage, Transportation and Disposal of Devices

The **Perenio**<sup>®</sup> Leak Sensor may be shipped by any kind of covered vehicles (by rail, or road or in sealed heated airplane compartments, etc.) in accordance with the requirements of current regulatory documents applicable to fragile goods sensitive to moisture.

Similar conditions shall apply to the device storage at the Seller's warehouse.

In accordance with the Waste Electrical and Electronic Equipment (WEEE)\* regulations, all electrical and electronic products must be collected separately at the end of their service life, and cannot be disposed of together with unsorted household waste.

Parts of worn out devices must be separated and sorted by the material type. In this way, every user can contribute to reuse, recycling and other forms of recovery of waste electrical and electronic equipment. Proper collection, recycling, and disposal of such devices will help avoid potential environmental and health impacts from the harmful substances they contain.

To dispose of the device, it must be returned to the point of sale, or to a local waste collection and recycling company recommended by the state or local authorities. Disposal is carried out in accordance with the applicable laws and regulations of the respective country.

For more details on how to properly dispose of your used device, please contact your device supplier, your waste disposal service or the local authorities responsible for waste disposal.

**NOTE.** The User must comply with the temperature and humidity conditions of storage and transportation specified in the Table of technical specifications of the present Installation and Operation Manual.

\* Waste Electrical and Electronic Equipment, or WEEE, means used electrical or electronic equipment, including all components, assemblies, consumables that are part of the equipment at the time it is taken out of service (including supplied batteries (if any), components containing mercury, etc.).

## 6 Other Information

### Manufacturer

Name	<i>Perenio IoT spol s r.o.</i>
Address	Na Dlouhem 79, Ricany – Jazlovice 251 01, Czech Republic
Contact Info	perenio.com, info@perenio.com

### Importing Company

Name	<i>ASBISc Enterprises PLC</i>
Address	43 Kolonakiou Street, Diamond Court, Ayios Athanasios, 4103 Limassol, Cyprus

### Quality Claims Acceptance and Warranty Service Company

Name	<i>ASBISc Enterprises PLC</i>
Address	43 Kolonakiou Street, Diamond Court, Ayios Athanasios, 4103 Limassol, Cyprus
Czech Republic	
Name	<i>ASBIS CZ, s.r.o.</i>
Address	Obchodní 103, Čestlice, 25101

### Info on Certificates and Declarations

Certificates	EU-Type Examination (Module B) Certificate #18-210982 as of May 5, 2018
Declarations, Reports	EMC Test Report #STS183222E01 as of March 27, 2018; Test Report #STS183222A01 as of March 29, 2018; Radio Test Report #STS183222W01 as of March 31, 2018; Radio Test Report #STS183222W02 as of March 31, 2018.

Addresses of Service Centers are available at **perenio.com** in the "Support" Section.

## 7 Troubleshooting

Table below shows typical errors and problems that may occur in the process of connection and configuration of the Leak Sensor.

Table 3 – Typical Errors and Troubleshooting Methods

Item No	Problem	Possible Reasons	Solution
1	No alarms in the case of leakage	Two leakage detectors are not in a full contact with the liquid	Level the sensor properly on a horizontal surface
2	Alarms in the absence of leaks	The surface between leakage detectors contains liquid	Dry the surface in the area of leak detectors
3	The sensor changes status to "offline" unexpectedly	Low battery level of the sensor, or it is out of the Zigbee coverage	Change the battery or reduce the distance between the Sensor and the Control Gateway/IoT Router

## 8 Glossary

<b>ABS</b>	Modern synthetic polymer with a high level of impact resistance and elasticity
<b>CG</b>	The <b>Perenio®</b> PEACG01 Control Gateway
<b>DSP</b>	The Digital Signal Processor is a special microprocessor designed to ensure digitized signal handling (usually, in real time mode)
<b>IoT</b>	The Internet of Things is a system of Internet-connected devices able to collect and exchange data coming from built-in services
<b>IP67</b>	Degree of protection of the casing indicating that the device is fully protected from the penetration of dust and is suitable for short immersion in water under conditions established by the manufacturer
<b>Location</b>	General term which means a building or a structure in which <b>Perenio®</b> Cameras, Control Gateways and/or Sensors are installed
<b>Perenio Smart</b>	Software developed by <i>Perenio IoT</i> for remote control of wireless Cameras from smartphones
<b>Zigbee</b>	A network protocol designed for secure transmission of data at low speeds, which is recognized for an extremely low power consumption